Fs2 Hexa-Core

User Manual

Welcome to your new **Fs2 Hex-Core** by **FOMO*stream*®**

- Before using your unit, please carefully read the instructions to ensure you use it safely and correctly.

- The instructions in this User Manual are based on the preset settings of the Fs2 Hexa-Core.

- Usable functions and supplementary services are changeable for the device, software and service providers.

Specifications

OS	Android 7.1.2
CPU	Dual Cortex-A72 + Quad Cortex-A53, 64-bit Frequency
GPU	Mali-T864 GPU, OpenGL ES1.1/2.0/3.0/3.1, OpenVG1.1, OpenCL, DX11
DDR	4GB_DDR3
eMMC	16GB/32GB
ExpandMicroSD	T-Flash(Maximum support 64GB
Video Format	MPEG-1, MPEG-2, MPEG-4,H.263, H.264, H.265,AVS, VC-1, RV, VP6/VP8,MVC (1080p) Sorenson Spark, MVC up to 4K*2K @ 120fps
Audio Format	MP1,MP2,MP3,WMA,WAV,OGG,OGA,APE,FLAC,AAC,M4A,3GPP etc
Music	Can be connected to the internet, enjoy music online

| WiFi	802.11 b/g/n
Bluetooth	Ver 4.0
Ports	HDMI 2.0, Micro SD X1, USB 2.0 x 1 ,USB 3.0 x1, RJ45X1 ,Audio outx1 , DC IN(5V 3A)
Accessory	HDMI cable, Remote control, power adapter, manual
Flash	Supports flash 11.x or later.

Explanation of Ports

IR

LED

DC   output   USB 2.0   TF Card   Duel Frequency wifi Antenna

DC 5Vin   Recovery   HDMI   USB 3.0   Ethernet

Instructions for Remote Control

- Indicator
- off/ standby
- Menu
- Navigation upward
- Navigation on the left
- OK
- Navigation on the right
- Navigation downward
- Back
- Main menu
- Sound -
- Sound +

Basic Spare Parts List

- Fs2 Hexa-Core
- 2.4-5.8G WIFI Antenna
- 5V-3A DC Power Supply
- HD HDMI cable
- User Manual

Solutions to Common Questions

- **The display is not working**
<u>Solution</u>: Unplug and replug the power supply. The 4K logo on the top will light up in blue when the box is functioning properly.

- **The display is not relaying to the TV**
<u>Solutions</u>: Check to see that the HD cable is connected properly. Try a new HD cable. Try a new monitor.

- **The Infrared is not functioning**
<u>Solution</u>: Make sure that the remote control batteries have enough power. When pressing the remote control the indicator light should glow red.

Android 8

FOMOstream.com